## Part# 7669

Note: When installing the mount, start all bolts and mount the alternatorr before tightening. 3/8" Nylock Nut 1/4" Spacer 3/8 or 7/16 x 1" 3/8 x 3/4 3/8 x 3" 2" Spacer 3/8 or 7/16 x 31/4" 1 5/16" Spacer (Top Water Pump)

**NOTE:** Some heads have 3/8" bolt holes and some have 7/16". This kit includes both sizes of bolts for these holes.

If your head has 7/16" it will be necessary to enlarge the corresponding holes in the mount to 7/16".

> **Belt info.** We use a belt length of 52-53" with this mount on installations in our shop. However; this can vary with the diameter of your pulleys.

Standard belt widths are 3/8" and are designated by the first number in the belt part number. Belt width by brand are as follows:

Gates: 7 Series followed by length AC Delco: 15 Series followed by length Dayco: 15 Series followed by length NAPA: 15 or 25 Series followed by length

## **Disclaimer**

- The purchaser is responsible for determining the suitability of any or all products purchased from Tuff Stuff Performance Accessories LTD.
- The customer recognizes that Tuff Stuff products may not be a direct replacement for their original, and some modifications may be necessary.
- Tuff Stuff will not influence your use of this product in your vehicle in any manner.
- Any Tuff Stuff product shall be installed at your own discretion.
- Remember: Any Tuff Stuff product must be installed by a professional mechanic.
- Chrome plated products returned for proposed warranty with scratches or chips will not be considered for refund or replacement.



Alternator Mount 7669

Big Block Chevy - Drivers Side Short Water Pump